

skware™ table top assembly instructions

FOR WOOD, BAMBOO, CORIAN, & LAMINATE



SAFETY TIP!

Assemble with at least 2 people at or near final location of table.

SCREW ATTACHMENT

STEP 1: TABLE FRAME

- Assemble table on a flat stable surface with plenty of surrounding space.

STEP 2: PLACE TOP & ALIGN

- Place top on frame and square corners ensuring an even, smooth edge all around.

STEP 3: SECURE TOP TO FRAME

- With top squared and aligned, drill one 3/4" screw through mounting tab in corner into the top.
- Check top alignment and adjust as needed.
- Drill second screw through the mounting tab diagonally across in opposite corner.
- Drill remaining screws through mounting tabs into table, ensuring a snug fit.

FOR QUARTZ, GRANITE, & OTHER STONE MATERIALS



SILICON ATTACHMENT

STEP 1: TABLE FRAME

- Assemble table on a flat stable surface with plenty of surrounding space.

STEP 2: APPLY ADHESIVE

- Using clear heavy duty silicon adhesive, apply a 1/4" bead of silicon along all mounting tabs.

STEP 3: SECURE TOP TO FRAME

- Lightly place top ensuring alignment to frame with silicon.
- Square corners ensuring an even, smooth edge all around.
- Apply even balanced pressure to top to secure grip between table top and frame.

STEP 4: ADHESIVE DRY TIME

- Follow drying instructions written on adhesive packaging and let table sit for at least 12 hours.