

# care instructions

## Acrylic Products

### magbox™

- magbox™ is designed for use with periodicals, brochures, and flyers.
- To transport, place fingers inside the handle ports on the sides of the magbox™.
- Use two hands at all times when transporting the magbox™.
- DO NOT use the current issue divider to transport the magbox™.
- DO NOT drop your magbox™. Drop damage is not covered under warranty.

### magbrowz™

- magbrowz™ is designed for use with board & picture books, Blu-rays, DVDs, CDs, and video games.
- DO NOT transport the large magbrowz™ bin or tray with materials inside. Empty materials completely before transporting the large magbrowz™ bins or trays.
- To transport, place fingers inside the handle ports on the sides or carry from beneath.
- Use two hands at all times when transporting the magbrowz™.
- DO NOT drop your magbrowz™. Drop damage is not covered under warranty.

### magstak™

- magstak™ is designed for use with paperback & hardcover books, Blu-rays, DVDs, CDs, and video games.
- Refer to assembly instructions and utilize binding posts and connector bolts between modules for stability.
- DO NOT transport the magstak™ modules with any materials inside or the base with modules on top. Empty materials completely, remove any signage components, and disassemble before transporting. If you have the modules fastened with connector bolts, remove them first (refer to assembly instructions for guidance).
- To transport, use two hands to grip the sides of the empty magstak™ modules.
- Use only 32 lb paper for signage, to ensure proper fitting into the sign holder.
- DO NOT drop your magstak™ modules. Drop damage is not covered under warranty.

### cleaning

- Clean with a damp soft cloth only. For major cleaning, use NOVUS No 1 cleaning solution.
- DO NOT use window cleaning sprays, scouring tools, acetone, benzene, or lacquer thinner for cleaning.
- Hairline fractures are normal occurrences. They do not affect functionality or product aesthetics and are not covered under warranty.

## Discovery™ Activity Tables

### cleaning

- Clean table surfaces with a damp soft cloth only.
- For minor wood nicks and scrapes use fine grit sandpaper. Use wood filler for larger damage.
- DO NOT use scouring tools, acetone, benzene, or lacquer thinner for cleaning.



## Discovery™ Play End Panels

cleaning

- Keep liquids, markers, glue, and craft supplies away from all play surfaces.
- For wood surfaces, clean with a damp soft cloth only. For major cleaning, gently use a mild wood cleaner.
- DO NOT use window cleaning sprays, scouring tools, acetone, benzene, or lacquer thinner.
- Hairline fractures are normal occurrences. They do not affect functionality or aesthetic.

## Engage Collection

- magnetic and countertop sign holders are designed to display wayfinding and collection signage graphics.
- sloped, face-out, and zig zag displays are designed for use with featured titles, books, CDs, DVDs, paperbacks, and more.
- If provided, refer to assembly instructions.
- DO NOT transport product with any materials on them. If necessary, remove any signage components, and disassemble before transporting.
- Use two hands at all times when transporting.
- DO NOT drop, drop damage is not covered under warranty.

cleaning

- Clean with a damp soft cloth only. For major cleaning, use NOVUS No 1 cleaning solution.
- DO NOT use window cleaning sprays, scouring tools, acetone, benzene, or lacquer thinner.
- Hairline fractures are normal occurrences. They do not affect functionality or aesthetic.

## Tables: Maker, Kurve and Skware Collections

top / surface finishes

### **butcher block**

cleaning

- Clean with warm water and a damp soft cloth and work with the grain of the wood.
- If necessary, a mild dish soap can be used and diluted vinegar can be used to disinfect. Rinse with clear water using a clean, non-abrasive cotton cloth.

### **High pressure laminate with PVC edge**

cleaning

- Clean with water and a damp soft cloth.
- Use a mild soap if desired, but avoid harsh cleaners. Rinse with clear water using a clean, non-abrasive cotton cloth.



## **Solid surface & quartz**

cleaning

- Clean with water and a damp soft cloth.
- Use a mild soap if desired, but avoid harsh cleaners. Rinse with clear water using a clean, non-abrasive cotton cloth.

## **phenolic resin**

cleaning

- Clean with water and a damp soft cloth.
- For light scratches and scuff marks, clean the area thoroughly with mild soap and water, then apply a light coat of an oil based product (ie WD-40). This will bring back color of the surface.

base finishes

## **powder coated steel**

cleaning

- Clean with a damp soft cloth only.
- Do not leave standing water near levelers/casters.
- Use a mild soap if desired, but avoid harsh cleaners. Rinse with clear water using a clean, non-abrasive cotton cloth.

## **brushed stainless steel**

cleaning

- Clean with a damp soft cloth only.
- Use stainless steel cleaner when necessary.

